



FD-A047913



Electronics Division

This submittal applies to AN/BRN-7 (Submarine Ω) only.
This submittal applies to AN/SRN-() (Hydrofoil Ω) only.
This submittal applies to both AN/BRN-7 and AN/SRN-().
CONTRACT NO: N00039-73-C-0209
PROGRAM NAME: AN/BRN-7
CDRL No: AOID, AOIE, AOIF
Title of CDRL: Computer Program Design Specification Computer Subprogram Design Document Data Base Design Document
Title of Doc: AN/BRN-7 Computer Program Specification NORT 73-48 Volume 2 thru 13
Date: 1/16/74
Initial Submittal: X Release 19-16-74
Resubmittal: Authentication
Prepared by: System Integration Unit Orgn. Name
Orgn. No. and Ext. DDC
Approved by:

News of Okak Supervisor of Preparing Orgn. Program Mgr.

Proj. Engr. /Proj. Mgr.

FORM 6512 (2-72)

Approved for public release;
Distribution Unlimited

Copy No. 4

NORT 73-48

AN/BRN-7 COMPUTER PROGRAM SPECIFICATION

Volume VIII
NAVIGATION SUBPROGRAM DESIGN
October 12, 1973

ACCESSION INF

White Section X

BDS Goty Section X

WEARNOUNCED

JUSTIFICATION

Per DDC Form 50

BY ON File

BISTRIBUTION AVAILABILITY COOKS

THE AVAILABILITY COOKS

Approved by

G. W. Hauser

Director, Engineering Navigation Department

Volume VIII of the AN/BRN-7 OMEGA COMPUTER PROGRAM SPECIFICATION

Volume

I	Performance Specification
II	Design Specification
III	Synchronization Subprogram Design
IV	OMEGA Processing Subprogram Design
V	Tracking Filter Subprogram Design
VI	Kalman Filter Subprogram Design
VII	Propagation Prediction Subprogram Design
VIII	Navigation Subprogram Design
IX	Executive Subprogram Design
X	Control-Indicator Subprogram Design
XI	Built-in Test Subprogram Design
XII	Common Subroutines Subprogram Design
IIIX	Appendix

Electronics Division

CONTENTS

Section		Page
1	SCOPE	1
1.1	Identification	1
1.2	Subprogram Tasks	1
1.2.1	Velecity Processing	1
2	APPLICABLE DOCUMENTS	3
3	REQUIREMENTS	4
3.1	Detailed Description	4
3.1.1	Reference Labels to Flow Diagrams	4
3.1.2	Discussion	4
3.1.3	Flow Diagram Description	5
3.1.4	Description of Subroutines Used by the Navigation Subprogram	8
3.2	Flow Charts	8
3.3	Cumputer Subprogram Environment	15
3.3.1	Computer Subprogram Tables	15
3.3.2	Computer Subprogram Temporary Storage	15
3.3.3	Input/Output Formats	15
3.3.4	Required System Library Subroutines	15

SECTION 1

SCOPE

1.1 IDENTIFICATION

Volume I, Submarine OMEGA Computer Program Performance Specification, defines the functional requirements for the Submarine OMEGA Computer Program which is used by the AN/ARN-99 OMEGA Navigation Set. The Navigation set and the OMEGA program together comprise the Submarine OMEGA Navigation System. The tape which defines the computer program is entitled AN/BRN-7 Navigation Program.

Volume II, Submarine OMEGA Computer Program Design Specification, allocates the functional requirements of Volume I to the computer routine and subprogram level.

This volume describes the subprogram designated as Navigation, which has two abbreviations in the program listing (Volume XIII) due to the fact that NAVIGATION is composed of two routines: the Velocity Processing Routine with the abbreviation VP; and the RIJ Update Routine with the abbreviation RU.

1.2 SUBPROGRAM TASKS

1.2.1 Velocity Processing (See Figure 1)

- a) The incoming Velocity and Heading data must be read from the analog-todigital synchro inputs, then smoothed if necessary.
- b) The Velocity/Heading mode marker must be checked to determine whether the synchro or manual inputs will be used.
- c) Uncorrected velocity is then resolved to the ${\rm R}_2$ and ${\rm R}_3$ reference axes.
- d) Velocity is corrected, using corrections from the Combinational Filter.

1.2.2 RIJ Update

- a) The rotational correction terms must be calculated.
- b) The correction terms are then used to rotate the RIJ matrix.
- c) The Wander Azimuth Angle is computed for use by other programs.




FIGURE 1 VELOCITY PROCESSING

SECTION 2

APPLICABLE DOCUMENTS

a) Submarine OMEGA Computer Program Performance Specifications, Volume I of the Submarine OMEGA Computer Program Specification.

Applicable Sections:

- 3.1.1 Omega Task and System Breakdown
- 3.3.13 Velocity and Heading Processing
- 3.3.14 Navigation
- b) Submarine OMEGA Computer Program Design Specification, Volume II of the Submarine OMEGA Computer Program Specification.
- c) NORT 68-66, NAP70 User's Manual, July 1968.
- d) NORT 68-115A, Detailed Description of NDC-1070 Computer Instructions, Revision A, February 1970.
- e) NORT 69-87A, NDC-1070 Flow Chart Program, User's Manual.

SECTION 3

REQUIREMENTS

In order to understand the program description contained in the following pages, it is necessary that the reader will have become familiar with the associated functional requirements found in Volume I, Performance Specification, and with the subprogram allocation found in Volume II, Design Specification.

3.1 DETAILED DESCRIPTION

3.1.1 Reference Labels to Flow Diagrams

The code used to reference the particular block in the flow diagrams, Section 3.2, is as follows: The first number is the page number found in the upper right corner of the diagrams. This will be followed by a slash sign (/) to separate the page number from the block designator. The designator will either be a mnemonic label (e.g., TEST SYNC), a local label indicated by a dollar sign (\$), or an integer. The two types of labels reference the particular information block, on the given page, to which the label is attached. The integer number, n, means that the referenced block is the nth block from the top of the page; P8/3 would refer to page 8 and the third information designation down.

Finally, the label P1/\$2+3 refers to page 1, and the 3rd information block after the label \$2. Similarly, P2/7,8,9 refers to page 2 and blocks 7 through 9.

3.1.2 Discussion

The Navigation Subprogram is handled by the Five-Millisecond Interrupt Routine of the Executive Subprogram, and is separated into two non- Ω -tasks: Velocity Processing (VP), and RIJ Update (RU). As part of the non- Ω -task table these routines are called at a frequency of 10/second.

a) Velocity Processing: This routine processes the velocity and heading data which is input from either the E.M. Ship's Log (velocity) and the Mark 19 Repeater (heading), and/or the respective manual inputs from the Control-Indicator. If the data are from the external sources, the inputs will be smoothed before processing. This is not necessary for the manual inputs.

The submarine velocity input is resolved into the system axes (R_2 and R_3) and then corrected by velocity increments from the combinational filter.

Electronics Division

b) RIJ Update: The iterative updating of the position matrix is performed by converting the velocity over the last iteration into the effective angular rotation about each of the system axes. These rotations are then used to generate the rotation update matrix. The update matrix is multiplied by the previous position matrix to yield the change of position. Periodically the Kalman routine will be generating positional corrections. These will be added to and processed with the rotations generated from the velocity.

3.1.3 Flow Diagram Description

3.1.3.1 Velocity Processing

P1/VELOCITY PROCESSING

Sets up address of synchro data and index to read the synchro inputs.

a) <u>Smoothing</u>:

p1/VELOCITY PROCESSING \$1 through p2/1

This loop reads and, if necessary, smooths the incoming data. The first input is heading. The loop through \$2 is the process of data accumulation.

Set
$$Z = (\psi_A - \psi_{AO})$$

Test $|Z| > 4.4^{O}$?

Yes:
$$\psi_{A} = 0.02 \text{ Z} + \psi_{Ao}$$

Continue

No:
$$\psi_{Ao} = \psi_{A}$$

The second time through the loop, velocity is smoothed.

Set
$$Z = (V_{TAS} - V_{TASo})$$

Test $|Z| > 12.2 \text{ knots } ?$
 $Yes: V_{TAS} = 0.02 Z + V_{TASo}$
Continue
 $No: V_{TASo} = V_{TAS}$

b) Check Mode:

p2/2 through p3/\$33

The program must check the velocity/heading mode set by the operator via the Control-Indicator: if MAN Marker true, use manual velocity heading inputs; if VEL Marker true, use manual velocity and smoothed heading; if LOG Marker true use both smoothed values above. Now let V_{AT} and ψ_{A} = velocity and heading input from either the output of the smoothing routine or the manual input (Control-Indicator).

c) Uncorrected Velocity Resolution:

p3/\$33 + 1

Subroutine RESOLVE

$$V_2 = V_{AT} \sin (\theta_p + \psi_A)$$

 $V_3 = V_{AT} \cos (\theta_p + \psi_A)$

p3/\$33 + 2 through p4/2

Override using Program Monitor Unit.

Electronics Division

d) Velocity Corrected:

p4/\$12 through p4/\$14

If a new NAVMODE is not indicated, then set:

$$v_{C2} = v_2 + \delta v_2$$

$$v_{C3} = v_3 + \delta v_3$$

3.1.3.2 RIJ Update

a) Rotational Correction Terms:

p5/RIJ UPDATE through p5/RIJ UPDATE + 1

$$\Delta \theta_2 = -\left[1 + e \left(1 - 2 r_{11}^2 + r_{31}^2 - r_{21}^2\right)\right] \frac{V_{C3} \Delta t_{NAV}}{R_o}$$

$$^{-2e} \quad ^{r}21 \quad ^{r}31 \quad \frac{^{v}C2}{^{R}O} \quad ^{\Delta t}NAV + \delta \Theta_{2}$$

$$\Delta\theta_3 = \left[1 + e \left(1-2 r_{11}^2 - r_{31}^2 + r_{21}^2\right)\right] \frac{V_{C2} \Delta t_{NAV}}{R_o}$$

+2e
$$r_{21} r_{31} \frac{v_{C3} \Delta t NAV}{R_o} + \delta \theta_3$$

p5/RIJ UPDATE +2

Set
$$\delta \theta_2 = \delta \theta_3 = 0$$

Electronics Division

b) R Matrix Rotation:

p5/RIJ UPDATE +3

Subroutine ROTATE RIJ's

$$\begin{bmatrix} \Theta \end{bmatrix} = \begin{bmatrix} -(\Delta \Theta_2^2 + \Theta_3^2) & \Delta \Theta_3 & -\Delta \Theta_2 \\ -\Delta \Theta_3 & -\frac{\Delta \Theta_3^2}{2} & \Delta \Theta_2 \Delta \Theta_3 \\ \Delta \Theta_2 & \frac{\Delta \Theta_2 \Delta \Theta_3}{2} & \frac{-\Delta \Theta_2^2}{2} \end{bmatrix}$$

$$R_{ij_{new}} = R_{ij_{old}} + [\theta]_{3x3} R_{ij_{old}}$$

c) Wander Azimuth Angle:

p5/RIJ UPDATE +4

$$\theta_{\rm p} = {\rm TAN}^{-1} \left[\frac{{\rm r}_{21}}{{\rm r}_{31}} \right]$$

Exit

3.1.4 Description of Subroutines Used by the Navigation Subprogram

a) SMOOTH (page 6)

The subroutine will smooth a noisy data input with the last input. As indicated in 3.1.3.1-a, the new data less the old data is checked to see whether it is greater in absolute value than 4.4° = 12.2 knots (i.e. on synchro input reference).

If so, then it is smoothed as indicated.

If not, then the input data is used.


3.2 FLOW CHARTS


The Navigation Subprogram flow charts are presented on the following pages.


. THE OPERATOR. IT IS A NON OMEGA TASK THAT IS EXECUTED EVERY . TENTH OF A SECOND. VELOCITY PROCESSING 100 MILLISECOND MONITOR SIGNAL FOR MALF INDICATOR SET PROGRAM SEQUENCING SET UP INDEX TO READ 3 SYNCHRO INPUTS FROM DMA 1=TRUE HDG 2=UNUSED 3=SHIPS LOG READ SYNCHRO INPUT INCREMENT OCTANT AND EXTRACT QUADRANT FROM BITS 12 AND 13 SCALE QUADRANT AT PI EXTRACT TAN/COTAN FROM BITS 1-10 RESCALE TO BO USE AS SINE SET COSINE - 1 USE ARCTAN TO GET ANGLE AT PI BASE ANGLE NOW BETHEEN 0 AND 45 IS IT A COTAN? NO CORIGINAL OCTANT = 1, 3, 5 OR 7) COMPLIMENT ANGLE NEW BASE BETHEEN 315 AND 360 DEG 25 ADD QUADRANT TO GET FINAL RESULT SAVE IN RIS STACK SMOOTH INPUT WITH OLD DATA TO ELIMINATE BIG JUMPS DUE TO NOISE BSV SMOOTH

VELOCITY PROCESSING

THIS PROGRAM READS AND CONVERTS THE THO SYNCHRO INPUTS (SHIPS LOG
 AND TRUE HEADING) INTO A USABLE FORM. IT COMPUTES THE VELOCITY
 ALONG THE R2 AND R3 AXIS BASED ON THE NAVAGATION MODE SELECTED BY







. THIS IS A NON OMEGA TASK THAT UPDATES . CRAFT POSITION 10 TIMES A SECOND RIJ UPDATE INTEGRATE COMPUTED VELOCITY VC2.3 . DELTA T / RHO = ANG2.3 RHO = EARTH EQUATORIAL RADIUS TO GET ANGULAR CHANGE ALONG R2. R3 COMPUTE DELTA THETA 2 = -(1 + E(1-2R11**2 + R31**2 - R21 ** 2)) * (ANG 3) - 2ER21R31 . (ANG 2) + KALMAN CORRECTION 2 COMPUTE DELTA THETA 3 - (1 + E(1-2R11**2 - R31**2 ' + R21 - 2)) + (ANG 2) + 2ER21R31 (ANG 3) + KALMAN CORRECTION 3 CLEAR KALMAN CORRECTIONS 2,3 (THEY WILL BE NON ZERO AT MOST ONCE PER 10 SECONDS) UPDATE RIJ MATRIX HITH DELTA THETA 2, DELTA THETA 3 BSV ROTATE RIJS COMPUTE THETA P = ATAN R21/R31 SAVE THETA P. SIN (THETA P)


AND COS (THETA P) FOR OTHER

PROGRAMS

BBK

RIJ UPDATE

- . SYNCHRO SMOOTHING ROUTINE
- . THIS PROGRAM HILL SMOOTH THE NEW
- . SYNCHRO INPUT IF IT IS SUBSTANTIALLY
- . DIFFERENT THEN THE OLD VALUE



3.3 COMPUTER SUBPROGRAM ENVIRONMENT

3.3.1 Computer Subprogram Tables

None.

3.3.2 Computer Subprogram Temporary Storage

All temporary storage for the Navigation routine is contained in the R15 pushdown stack.

3.3.3 Input/Output Formats

DMA words $^{1A}_{16}$ through $^{1F}_{16}$ receive inputs from the Analog-to-Digital Converter. One word is brought in during the last one-third of each 5-millisecond period, with all right words cycled every 40 milliseconds. DMA word 1A contains the true heading input and word 1B contains the ship's log input. Each of these inputs is from a synchro with either a tangent or cotangent in bits 1 to 12 of the input word. These bits define the synchro input within a single octant (45 degrees). Bits 14 to 15 of the input word define the correct octant. The first octant is 0 and bit 14 true defines the second octant. Bits 1 to 12 represent a tangent for octants 0,3,4, and 6; otherwise they contain a cotangent.

Word 1A converts directly to true heading. Word 1B is shifted 120° from zero so that it is necessary to subtract 120° from the synchro value before converting to velocity. The conversion factor is 40 knots per 360° .

3.3.4 Required System Library Subroutines

Subroutine	Functional Description (Section 3.1.3)	Flow Diagram	Subprogram Design Document (by Volume Number)
RESOLVE ATAN SIN/COS ROTATE RIJ's	(a) (b) (b) (b)	3/\$33 + 1 60/RIJ UPDATE + 4 60/RIJ UPDATE + 4 Page 61	XII Common Subroutine XII Common Subroutine XII Common Subroutine XII Common Subroutine